



# OPERATING PROCEDURE

IMEC EBS16 - MIST SPRAY SANITIZER  
BATTERY OPERATED



YOUR HYGIENE PARTNER

SERVICE HOTLINE

+603 8734 9255

+6016 380 2999

technical@imec.com.my



1



## PREPARATION BEFORE START THE MACHINE



Mask

Glove

- 1 Ensure the facilities free from people
- 2 Wear suitable protection

## 2 Prepare all the ACCESSORIES needed



Detergents dilution

Full charging battery

Nozzles

## 3 Check SWITCH & PLUG TOP



Ensure switch is functioning.

## 4 Assemble ACCESSORIES



Fill in diluted detergents into the tank.

Insert suitable nozzle that suit the cleaning task.

## 5 Turn ON machine



1 Switch on the power

2 Install accessories

3 Machine is ready to use

## 6 During OPERATION

- ✓ Standing with the sprayer nozzle approximately 2–4 feet away from surfaces
- ✓ Spray individual surfaces and objects, working from high to low areas using a slow, side to side motion until surfaces are covered with disinfectant



## 7 During OPERATION

- ✓ Spray surfaces to ensure visible wetness for the desired contact time
- ✓ Wiping is not required to ensure surface disinfection; however, you may choose to wipe specific surfaces to polish them (e.g., glass, mirrors) or to remove visible residue after the contact time is achieved







# OPERATING PROCEDURE

IMEC EBS16 - MIST SPRAY SANITIZER  
BATTERY OPERATED



YOUR HYGIENE PARTNER



SERVICE HOTLINE

+603 8734 9255

+6016 380 2999

technical@imec.com.my

## 8 AFTER USE THE MACHINE



## 9 Clean ACCESSORIES



## 10 Clean ACCESSORIES



## 11 Recharge the BATTERY



## 12 Store the MACHINE



## SUITABLE CHEMICALS THAT CAN BE USE WITH EBS16



556 Sanitise

1:60  
(Mist Spray/Mopping)

1:20 (Mist Spray/Wiping)

1:30 (Mopping)



580 Liquid Chlorine 25

1:100  
(Mist Spray/Mopping)

1:20  
(Mist Spray/Mopping/Wiping)

Dilution for Preventive Practice

Dilution for Infected Area Practice