




Introduction - Getting to know the 3 buttons



How to set the 24 hr clock

1. Press "CLOCK" till screen starts to blink
2. Adjust time using .
3. Press "CLOCK" to shift to the next blank and use  to adjust the time.
4. Press "CLOCK" and "RUN" together and hold till the colon flashes. Clock is set.

How to read the 24 hr clock

1. Screen shows clock in hour/min.

| | | | | |
|---|---|---|---|---|
| 1 | 2 | : | 4 | 5 |
|---|---|---|---|---|

This reads 1245

2. Press "CLOCK" again and screen shows min/sec

| | | | | |
|---|---|---|---|---|
| 4 | 5 | : | 2 | 3 |
|---|---|---|---|---|

This reads 45 min 23 sec

3. Press "CLOCK" again to return to hour/min screen

How to set duration for each run

1. Press “RUN” till the screen shows

| | | | |
|---|---|---|---|
| 0 | 0 | 0 | 0 |
|---|---|---|---|
2. Press

| |
|---|
| → |
|---|

 to shift to the next blank and

| |
|---|
| + |
|---|

 to adjust the time.
3. Press

| |
|---|
| ↵ |
|---|

 to enter.

For example: To set 10 sec run duration

| | | | |
|---|---|---|---|
| 0 | 0 | 1 | 0 |
|---|---|---|---|

1. Press

| |
|---|
| → |
|---|

 thrice and

| |
|---|
| + |
|---|

 once.
2. Press

| |
|---|
| ↵ |
|---|

 to enter.

How to set running time

1. Press “START” till the screen shows

| | | | |
|--|--|---|---|
| | | 0 | P |
|--|--|---|---|

. This means that no time has been programmed.

2. Press “START” once and screen shows

| | | | |
|---|---|---|---|
| - | - | - | - |
|---|---|---|---|

. Using

| |
|---|
| → |
|---|

 &

| |
|---|
| + |
|---|

3. Press “START” till once the screen shows

| | | | |
|---|---|---|---|
| 1 | P | 0 | 2 |
|---|---|---|---|

. This means that the 1st running time has been programmed (1 P) and whether to proceed to the next programme (02).

4. Press “START” once and screen shows

| | | | |
|---|---|---|---|
| - | - | - | - |
|---|---|---|---|

. Using

| |
|---|
| → |
|---|

 &

| |
|---|
| + |
|---|

5. Press “START” till once the screen shows

| | | | |
|---|---|---|---|
| 2 | P | 0 | 3 |
|---|---|---|---|

. This means that the two running time has been programmed (2 P) and whether to proceed to the next programme (03).

If you wish to proceed to the next programme,

6. Follow steps 2-3 repeatedly to programme the starting time for each run. A maximum of 12 runs can be programmed.

If you do not wish to proceed to the next programme,

7. Press “START” twice. The screen would return to the clock.

How to cancel or reset a particular set time

1. Press “START” till the screen reads

| | | | |
|---|---|---|---|
| 3 | P | 0 | 1 |
|---|---|---|---|

. This means that 3 starting times has been programmed and it refers to the 1st of the 3 starting times.

2. Press “START” once and the screen will show the 1st starting time. Use

| |
|---|
| → |
|---|

 &

| |
|---|
| + |
|---|

 to readjust the time if needed. If not, press “START” once.

If you wish to cancel this particular time,

Press

| |
|---|
| + |
|---|

 till any blank shows

| | | | |
|---|--|--|--|
| - | | | |
|---|--|--|--|

 followed by pressing “START”, the particular running time will be cancelled.

How to prime

1. Press Run & Start at the same time

IMEC HYGIENE SDN BHD